


The AQUAvalve5 is the patented, power-free water control device that regulates the supply of water and fertiliser to your Tray2Grow. These Simple Care Guidelines will help ensure your AQUAvalve5 functions perfectly and produces excellent results every time - for years to come.



Ensuring that the AQUAvalve5 floods and drains correctly

- 1** Making sure your AQUAvalve5 floods and drains correctly is simply achieved and only takes a few seconds.
- 2** Hold the AQUAvalve5 at eye level so that you can see the silicone fitted to the top float resting on the hole below it.
- 3** The silicone must create a tight seal when touching the hole.
- 4** If it looks like it is not sitting parallel on the hole below, simply lift the top float and apply pressure to one side of the silicone, drop the float and hold at eye level again. Repeat the procedure if necessary.
- !** Properly inserted, the silicone will ensure the AQUAvalve floods your tray to 20mm³/₄", closes, and then allows the tray to completely drain before reopening. An improperly inserted silicone may prevent the AQUAvalve from flooding and draining correctly.

Care and maintenance

- 1** At the end of your growing season, clean the AQUAvalve5 using warm soapy water. Using an old tooth brush will help. The AQUAvalve5 is easily disassembled. The top float will slide all the way across and the bottom float is unclipped from its pivoting position. The circular discs fitted to the top float can also be removed by using pliers to grip the raised point. At this point is it advisable to remove the silicones to avoid them being lost.
 - 2** It is also handy to have a paper clip or pipe cleaner to hand so that you can push it through the AQUAvalve5 nozzle, this will remove any limescale build-up that may have occurred during the growing season. Blowing through the AQUAvalve5 nozzle will also help to remove any build up.
- Do not use a drill and drill bit to clear the AQUAvalve5 nozzle. This will potentially damage the AQUAvalve5 beyond repair.**
- 3** Always flush pipework thoroughly at the end of the growing season to remove any sediment.



Set Up Tips


- 1** Always ensure the surface you're placing your tray on is flat and sound, ideally with reference to a bar spirit level. Avoid setting up on surfaces such as gravel as these aggregates can shift over time.
- 2** If using a grow bag, fluff it up to loosen the media and perforate the underside before placing in the tray to improve aeration and drainage.
- 3** If growing outdoors remove the Overflow Plug, allowing any excess water that may accumulate during rainfall to escape. If heavy rainfall occurs turn your reservoir off until rain has stopped and the water has been drained / consumed. If growing indoors leave the Overflow Plug in place.
- 4** If using Tray2Grow with pots, trays, or planters always pre-soak the capillary matting and root control sheet before fitting.



In-Use Tips

- 1** Once your bag, planter, pots, or trays are in place and planted up water them through with a watering can. Allow your plants to take up this water before switching the system on.
- 2** As grow bags typically include some degree of feed within the grow media it's often best to supply plain water for a few weeks before gradually introducing liquid feeds via the reservoir and pipework.
- 3** When using Tray2Grow with growbags irrigate judiciously in early stages. Consider switching on/off intermittently in order for plants to establish.
- 4** If using pots or seed trays always ensure that they have holes on the underside that allow your grow media to be in contact with the root control sheet and matting beneath. This is essential in order for uptake of water and/or nutrients to occur

mail@autopot.co.uk | www.autopot.co.uk | +44 (0)1276 534900




Tray2Grow Set-Up Guide

Contents

- | | |
|---------------------------------------|-------------------------------|
| 1x Tray2Grow Tray & Lid | 1x 9mm / 3/8" Tee Connector |
| 1x AQUAvalve5 | 3x Circular Spirit Level |
| 2x 9mm / 3/8" Grommet | 10x Capillary Spikes |
| 1m / 3.3ft of 9mm / 3/8" Pipe | 10x Capillary Strips |
| 1x 16-9mm / 1/2-3/8" Click-Fit Filter | 1x Capillary Matting |
| 1x 9mm / 3/8" Golf Filter | 1x Root Control Sheet |
| 1x 9mm / 3/8" In-line Tap | 4x Seed Trays |
| 1x 6mm / 1/4" Overflow Plug | 1x Slug Repellent Copper Tape |

Useful Information

Scan For Set-Up Video



Scan For Product Details




Winner - Best Growing And Planting Equipment




Garden Industry Manufacturers Association Awards


Initial Set-Up - All Methods




1 Position Tray2Grow on a level surface - use a bar spirit level to be sure. Avoid placing on gravel or similar aggregates. Insert and check spirit levels to ensure Tray2Grow is still sitting flat.




2 Insert 9mm / 3/8" top hat grommet into outside of tray. Push 30cm / 12" of 9mm / 3/8" pipe into the tray through the grommet. Wetting the pipe end with cold water helps harden it, aiding insertion.




3 Attach the pipe you've pushed inside the tray to the AQUAvalve. To do so, remove AQUAvalve collar. Push pipe through collar and attach to nozzle. Rescrew collar. DON'T overturn...when you feel it grip STOP




4 Remove any slack in the pipe by drawing excess out of the tray.




5 Align the 'half moon' section on the rear of the AQUAvalve with the 'T' section in the tray. Firmly push the AQUAvalve onto the 'T'.



6 If growing outdoors remove the 6mm / 1/4" Overflow Plug from the front of the Tray2Grow. If growing indoors keep this plug in place.




7 Place lid over the AQUAvalve compartment of the tray and press securely into position




! Optional - 9mm Tee Connector
Use the 9mm / 3/8" Tee Connector to connect multiple Tray2Grow systems to one reservoir.
To do this, cut your 9mm / 3/8" pipe at a point appropriate to your layout. Join the cut lengths to the tee. Attach your additional Tray2Grow system(s) to the spare connection on the 9mm / 3/8" tee connector.


Set-Up Guide A - Grow Bags




8a Loop capillary strips into grow bag spikes



9a Push the grow bag spikes into the base of Tray2Grow




10a Fluff up your grow bag and perforate the underside multiple times at random. Place your grow bag into the Tray2Grow



11a Plant up your grow bag and water through by hand




12a Use canes in the cane support holes if training vine crops




13 Apply slug-repellent copper tape all around the edge of the Tray2Grow


Set-Up Guide B - Trays, Pots & Planters




8b Wet and lay capillary matting into Tray2Grow - black side up, tuck capillary matting into two outer channels only.




9b Wet and lay root control sheet on top of the capillary matting. Lay root control sheet copper side up.




10b Place your planted-up seed trays or pots into Tray2Grow and water through. Pots and trays must have holes in the base that allow grow media to directly contact the root control sheet below.



11b If using a planter position planter in the Tray2Grow first




12b Then plant up the planter in Tray2Grow and water through




13b Apply slug-repellent copper tape all around the edge of the Tray2Grow


Untapped Reservoir Connection




UR1 Take the loose end of your 9mm / 3/8" pipe (the end outside your tray). Cut 7.5cm / 3" in from the end. Connect cut ends of pipe to 9mm / 3/8" inline tap



UR2 Make a 12mm / 1/2" dia. hole in your reservoir using a step drill. Push the 9mm / 3/8" grommet into your reservoir. Push 9mm / 3/8" pipe through grommet.




UR3 Inside the tank push the 9mm / 3/8" filter into 9mm / 3/8" pipe.




UR4 Fill your reservoir with water and fertiliser and switch on. See 'In-Use Tips 3' for notes on initial use with growbags.


Tapped Reservoir Connection




TR1 If necessary cut 9mm / 3/8" pipe to a length suitable for your setup.



TR2 Connect 9mm / 3/8" pipe to the 16-9mm / 1/2-3/8" Click Fit Adapter and Filter



TR3 Connect 16-9mm / 1/2-3/8" Click Fit Filter to your reservoir tap. If your tap is not Click-Fit remove the collar from the Filter and push pipe directly onto tap.



TR4 Fill your reservoir with water and fertiliser and switch on. See 'In-Use Tips 3' for notes on initial use with growbags.